

Outdoor Wireless Battery LED Inflatable Column Light



USER INSTRUCTION MANUAL

Thank you for purchasing the lamp from our company. Every product has been well tested and has shipped in perfect operating condition. When receiving our products carefully check the shipping carton for damage that may have happen during transport. In case of the damage inspect the fixture for the damages or missing accessories necessary to operate. If parts are missing or fixture has been damage please report this by Product.

Caution

Do not attempt any repairs yourself. Doing so will void your manufacturer's warranty. In the unlikely event your unit may require service please contact us

Warning

To prevent or reduce the risk of the electrical shock or fire, do not expose this unit to any moisture. Please read this manual carefully to familiarize yourself with basic operations of this unit

Safety precautions

1. Do not expose this unit to , wet moisture, explosive
2. Before plugging the power be sure local power outlets matches with the required voltage of the unit
3. Do not remove the cover under the circumstance in case you are not qualified to do so
4. Never connect the power when cover is removed
5. Never use this unit if it becomes damaged
6. Never connect this unit to any dimmer and / or power pack
7. If the unit will not be used for the long time , disconnect it from the power supply
8. Always mount this unit safe and stable and make sure the area will have proper ventilation. Take care this unit will not be mounted in an area close to heat sources such as lighting fixtures, amplifiers heat registers, stoves and radiators
9. Always contact us in case you have any doubts

DMX Channel table

1) A001: Channel table

Channel table	Channel name	numerical value	explain
1	Dimming	0~255	Total dimming
2	red	0~255	Linear dimming
3	green	0~255	Linear dimming
4	blue	0~255	Linear dimming
5	white	0~255	Linear dimming
6	Stroboscopic	0~255	From slow to fast strobe
7	effect	0~5	Manual color matching (red, green, blue, white,...)
		6~50	Gradient color change
		51~100	Pulse changing color
		101~150	Jump color
		151~200	Automatic mode
		201~255	Audio Mode
8	speed	0~255	Effect speed