

4X50W COB LED PAR USER MANUAL



1. Introduction
2. Safety Instructions
3. Installation
4. Operation
5. Maintenance
6. Troubleshooting
7. Specifications
8. Warranty

1. The Introduction of LED display panel:



1. MENU
2. UP
3. DOWN
4. ENTER

Press A button, there will be eight different effects.
The first two letters stands for functions (refer to Diagram II)
The last two letters stands for DMX address, or speed,.
You can modify it with B or C button. And press D button for confirmation.

2. Function of LED Display

NUM	NAME	VALUE	FUNCTION
1	d001	001- 512	DMX512 ADRESS
2	A001	001- 512	8CH
3	S-SL	SL/FA	DMX512 Dimmer speed SL:slow dimmer; FA:fast dimmer
4	d-Ho	Ho/oF	DMX Setting: Ho: keep Dmx; oF: Close All LED
5	rFye	ye/no	ye:Remote opening; no:Remote off.
6	r255	000 - 255	LED1 Dimmer
7	G255	000 - 255	LED2 Dimmer
8	b255	000 - 255	LED3 Dimmer
9	u255	000 - 255	LED4 Dimmer
10	F255	000 - 255	Strobe
11	CC15	00 - 15	Color Jump
12	DE15	00 - 15	Color Fade
13	CP15	00 - 15	Color Pulse
14	SU15	00 - 15	sound
15	t 30	00 - 99	Temperature

1. DMX512

4 Channel (d001 Mode)

Channel	Display	Function
CH1	C1 Dimmer	C1 Dimmer
CH2	W1 Dimmer	W2 Dimmer
CH3	C2 Dimmer	C2 Dimmer
CH4	W2 Dimmer	W2 Dimmer

8 Channel (A001 Mode)

Channel	Display	Function
CH1	Dimmer	Total Dimmer
CH2	C1 Dimmer	C1 Dimmer
CH3	W1 Dimmer	W2 Dimmer
CH4	C2 Dimmer	C2 Dimmer
CH5	W2 Dimmer	W2 Dimmer
CH6	Strobe	Strobe
CH7	Macro	
CH8	Macro Speed	