

Fault	Problem cause	Solutions
Engine won't start	Engine switch set to OFF	Setting the engine switch to
	Fuel tank is empty	Add fuel
	Engine contains dirty or old	Changing the fuel in the
	Low oil level	Add fresh oil to the recommended level
Reduced engine power/ troubled engine start	Fuel tank is dirty	Clean the fuel tank
	Air filter is dirty	Replace the air filter
	Water or air in the fuel line	Bleed off the fuel line
Engine overheating	Cooling tablets are contaminated	Clean the cooling tablets
	Air filter is dirty	Replace the air filter
Engine starts, but no output voltage	Breaker tripping	Set the breaker to ON
	Poor quality of connection cable	Check the cable for proper operation; if using an extension cable, replace it.
	Faulty connected device	Try connecting another device
Engine starter does not respond	Check starter wiring Check start battery	